



### STEP 1

Cut The End Of The Cable  
With A Set of Sharp Cutters

### STEP 2

Using Favorite Stripper Insert  
Cable As Shown. Don't Extend  
Past Body and Twirl Stripper Both  
Counterclockwise and Clockwise  
3 Times



### STEP 3

Pull Off The Stripped Material  
Fold Back Braiding Over Cable  
Jacket As Shown

### STEP 4

Insert Connector Onto Cable  
When Properly Inserted Dielectric  
Should Hit The Bottom Plate Of  
The Nut



### STEP 5

Insert The Connector Into Tool As Shown  
Compress Tool  
After Tool Has Been Compressed Release  
Remove Connector From Tool

